



Jeep Grand Cherokee WK2

2011-2019

Roof Rails Only



IMPORTANT! – READ BEFORE INSTALLATION

- This product must be installed exactly as per these instructions using only hardware supplied.
- Take a few moments to read instructions thoroughly before beginning work.
- In the event of damage to any component please contact OFFROAD ANIMAL to arrange repair/replacement of components.
- Do not use this product for any vehicle make or model other than that specified on these instructions.
- Do not remove labels from this product.
- This product and its fixings must not be modified in any way unless stated in these fitting instructions.
- The installation of this product is recommended for trained personnel.
- These instructions are correct at time of publication. OFFROAD ANIMAL cannot be held responsible for the impact of any changes subsequently made by the vehicle manufacturer. If you find something has changed please contact us to let us know!
- During installation it is the duty of the installer to check correct operation/clearances of all components.
- If Instructions are to be printed for reference in the workshop, it is recommended that they are printed in colour, for best legibility.
- Fitting Time: 45 min
- No loading applied to these rails as we do not know what rack you're going to put on it.

PARTS LISTING

IMPORTANT: Check all parts are present before beginning work! Contact OFFROAD ANIMAL if something is missing.

Main Parts – In the Box

Qty	Part Number	Description	Image
1	RR-JGC-WK2-11-ASM2L	ROOF MOUNT LH	
1	RR-JGC-WK2-ASM2R	ROOF MOUNT RH	

Small Parts – Contained in Small Parts Kit Bag

Qty	Part Number	Description
1	PINCH WELD BLACK 3M	PINCH WELD BLACK 14MM X 9MM X 3M
12	M6 X 20	M6 X 20 HEX ZINC 8.8
12	M6 MUD WASH	M6 MUD GUARD WASHER
12	M8 CN	M8 CAGE NUT
12	M8 FW	M8 FLAT WASHER
12	M8 X 25	M8 X 25 HEX BOLT ZINC 8.8

TOOLS REQUIRED

The following tools will be required to install the product.

Hand Tools	Power Tools	Workshop Equipment
<ul style="list-style-type: none"> -T30 Torx Bit -10mm Spanner -10mm Socket and ratchet driver -13mm Spanner -13mm Socket and ratchet driver -Side Cutters 		

GENERAL WARNINGS

Offroad Animal will not be responsible for other manufacturers or custom racks used on our rails. T



1. Remove factory rails on both sides. 4 screws in each. Once all screws have been removed pull forward then lift.

Tools Required

T30 Torx bit

Fasteners

Retain only if you want to refit these later



2. Lift off Rails and save only if you want to reuse later. Otherwise discard or sell. Clean roof as it's always filthy under there.

TOOLS REQUIRED

FASTENERS



3. Fit Pinch weld to short edge of roof rails. Trim excess off with side cutters

TOOLS REQUIRED

Side cutters

FASTENERS



4. Fit nutserts as shown in both rails (6 per rail). You can use needle nose pliers or screwdriver to push one end of cage in from side

TOOLS REQUIRED

Needle nose
pliers or flat head
screw driver

FASTENERS

M8 Nutserts (12)



5. Lift steel rail onto roof as shown. Repeat for other side

TOOLS REQUIRED

FASTENERS



6. Fit Rails to roof with M6 Hex bolts and mud guard washers. 6 per side.
7. Save M8 hardware for whatever rack you're going to put on.

TOOLS REQUIRED

10mm Spanner

FASTENERS

M6 x 20 Hex bolts
(12)
M6 mud guard
washers (12)